


John Deere Industrial Hydraulic Pumps

Instruction Guide



R101288 **4 CI**

- A. Suction 1-5/16"
- B. Suction 1-5/8"
- C. Pressure Port 1-1/16"
- D. Cooler Port

R101807 **3 CI**

- A. Suction 1-1/16"
- B. Suction 1-5/8"
- C. Pressure Port 1-1/16"
- D. Cooler Port

R13426 **4 CI**

- A. Suction 1-1/16"
- B. Suction 1-5/8"
- C. Pressure Port 1-1/16"
- D. Cooler Port